

# Triple Ergonomic Roll-On Warmer (110 g)



<b>Ref.:</b>	3020400022
<b>Voltage / Frequency</b>	110–240 V / 50–60 Hz
<b>Power:</b>	< 25 W
<b>Dimensions:</b>	Warmer: 145 x 75 x 40 mm Base: 60 x 215 x 100 mm
<b>Contents:</b>	3 warmers / 1 base + cable / 3 caps

## Description

Depilflax appliances and roll-on kits are designed and manufactured by Maystar to deliver premium salon waxing. Ergonomic roll-on warmer (110 g).

## Usage

1. Place the roll-on wax refill in the warmer.
2. Plug the warmer cable into a 220-V socket.
3. Select switch position I or II (if the appliance features the two options) as required:  
I – Working temperature: keeps the wax at optimal application temperature.  
II – High temperature: rapidly heats the wax.
4. When the roll-on is in the warmer and the switch is set to position II, the wax takes approximately 25 minutes to reach application temperature. After 25 minutes, we recommend changing the switch to position I.
5. Skin cleansing: Cleanse the treatment area to remove any leftover cream, make-up or sweat, then dry thoroughly.
6. The wax is at application temperature when the roller glides easily over a waxing strip.
7. Wax application: Slide the roll-on over the treatment area, applying the wax in the direction of hair growth.
8. Waxing strip application: Place a strip over the wax applied to the customer's skin and press gently to ensure adhesion.
9. Waxing strip removal: Tug off the strip parallel to the skin and against the direction of hair growth. Hold the skin around the treatment area taut with the other hand, especially if flaccid.
10. Repeat the operation until all hair has been removed. The waxing strip can be reused several times.
11. Leftover wax removal: After waxing, remove any leftover wax with Post-Epil Oil.
12. To finish, we recommend applying Post-Epil Mousse to delay hair regrowth and invigorate and fully moisturize the skin.
13. Roll-on warmer cleaning: We recommend removing all leftover wax from the warmer to keep it in optimal condition.